

Step 1: Downloading the Application

Download the program from the following link: [WINK Reset](#)

Step 2: Authorizing the Download (Browser)


Due to the advanced nature of the tool and its modifications to printer registries, some browsers may pause the download of the .exe file. In this case:

- 1) Go to the downloads list (**Ctrl + J**).
- 2) Select the **"Keep"** or **"Download anyway"** option.
- 3) Double-click the downloaded file to run the program.

Step 3: Bypassing the Windows SmartScreen Filter

Upon the first launch, Windows may display a message regarding an unknown publisher. This is a standard procedure for new software. To proceed:


- 1) Click the **"More info"** link (point 1 in the graphic below).
- 2) Select the **"Run anyway"** button (point 2 in the graphic below).



Step 4: Device Reset Procedure

After successfully launching the interface, connect the printer to the computer via a USB cable and follow the red numbering in the application window:

- 1) **Detect printer** - Click the device search button.
- 2) **Read counters** - Check the current waste ink pad consumption level.
- 3) **Enter key** - Input the purchased activation code.
- 4) **Reset counter** - Confirm the operation to restore printer functionality.



The screenshot displays the 'WINK Reset PRO' application window. The title bar includes the application logo, the text 'WINK Reset PRO', a globe icon, a UK flag icon, and standard window controls. The main interface is divided into a left sidebar and a main content area. The sidebar, titled 'Epson Printers (USB)', contains a 'Detect Printers' button with a refresh icon. Below this, a 'SUMMARY' box shows 'Detected: 0 USB devices'. The main content area features a large illustration of a laptop connected to a printer via a USB cable. Below the illustration are three buttons: 'Trial Reset (85%)' with a clock icon, 'Validate Key' with a key icon, and 'Reset Waste Ink Counter' with a gear icon. The bottom of the window contains a footer with the text: 'Independent tool. Epson® is a trademark of Seiko Epson Corp. The program is not an official product of the brand. v1.0.5'.

